



Foil Vinyl Sheets

Two Step Process for all Projects

Foil HTV Instructions for **Heat Press** Application

Step #1

- Create design and place your setting to mirror in your design space.
 - Tip: By mirroring your design you are flipping the placement so when you place the design down it is right side up.
- Place color shiny side down on your mat. Dull side (no color) is facing up during cutting.
- Place cut setting to low pressure.
 - Tip- Test cut until the outer shape weeds out easily around the inner shape.
- Weed away excess materials leaving only the desired design on the color side of vinyl for heat transferring.
- Place weeded vinyl design on the garment with color side up.
- Place item on the heat press with your design in the area you want to press.
- Place a cover sheet (Teflon paper or Parchment paper) over your design and press with medium pressure at 300°F - 315°F for 10 seconds.
- Open press and **hot peel** your design. Very important to **hot peel** to achieve best results.

Step #2

- Cut a piece of foil that is slightly larger than the vinyl and carefully place foil over the vinyl design. Make sure design is completely covered.
- Place a cover sheet (Teflon paper or Parchment paper) over your design and press with medium pressure at 300°F - 315°F for 10 seconds.
- Open press and **cold peel** your design. Very important to **cold peel** to achieve best results.
- Tip for Foil Vinyl - Foil material is a good option to layer on Glitter materials only. Foil vinyl doesn't layer well on other HTV vinyl materials.

Foil HTV Instruction for Hand Iron Application

Step #1

- Create design and place your setting to mirror in your design space.
 - Tip: By mirroring your design you are flipping the placement so when you place the design down it is right side up.
- Place color shiny side down on your mat. Dull side (no color) is facing up during cutting.
- Place cut setting to low pressure.
 - Tip- Test cut until the outer shape weeds out easily around the inner shape.
- Weed away excess materials leaving only the desired design on the color side of vinyl for heat transferring.
- Place weeded vinyl design on the garment with color side up.
- Set iron dial between Cotton and Linen pending the item you are pressing.
- Place on flat hard surface (Iron board is not recommended).
- To achieve best results, don't use the steam function on the hand iron.
- Place a cover sheet (Teflon paper or Parchment paper) over your design and press iron with firm pressure straight down for 30 seconds (pending the design).
 - Tip – Don't move iron slide to slide.
- Remove iron press and **hot peel** your design. Very important to **hot peel** to achieve best results.

Step #2

- Cut a piece of foil that is slightly larger than the adhesive and carefully place foil over the vinyl design. Make sure design is completely covered.
- Place a cover sheet (Teflon paper or Parchment paper) over your design and press iron with firm pressure straight down for 30 seconds (pending the design).
 - Tip – Don't move iron slide to slide.
- Remove iron press and **cold peel** your design. Very important to **cold peel** to achieve best results.

Material Recommendations for HTV Vinyl

- All products should be polyester or cotton. Nylon materials will not work.
- 100% Polyester
- 100% Cotton
- 50% cotton / 50% polyester

Care Instructions

- For best care we suggest waiting 24 to 48 hours before washing your garment.
- Suggest to turn item inside out and washing in cold water.
- Suggest to dry on low setting or hang dry item for best care.
- Suggest to stay away from using chlorine bleach.

HTS Recommendation for Project Tools

- HTS Cooling Block is a great tool to make sure your press is fully cooled off and applied.
- HTS Mini Tweedy or Tweedy Lites are a great help with weeding fine lines.